


# Quick Start Guide

## Appearance


1. Power button
2. Screen
3. Micro USB port
4. WPS button
5. RESET button



## Getting Started

### Installing

Install the SIM card, microSD card, and battery according to the illustration.



### Note:

The microSD card is an optional accessory. If no microSD card is included in the package, please purchase one separately.

## Charging the Battery

If the Mobile WiFi has not been used for a long time or if the battery is fully depleted, the Mobile WiFi may not power on immediately after the charger is plugged in. Please charge the battery for a while before attempting to power on the Mobile WiFi. Method 1: Use the charger to charge the device


### Note:

Only use chargers compatible with the Mobile WiFi and provided by a designated manufacturer. Use of an incompatible charger or one from an unknown manufacturer may cause the Mobile WiFi to malfunction, fail, or could even cause a fire. Such use voids all warranties, whether expressed or implied, on the product.


The charger is an optional accessory. If it is not included in the package, you may contact an authorized dealer to buy a charger compatible with the Mobile WiFi.

## Screen


### Home Screen



1. Signal strength.  
 : Connected to WAN.  
 : Connected to WLAN.
2. Network type  
 2G/3G/4G/4G+: Connected to an 2G/3G/LTE/LTE-A network.  
 APC: Work on APC mode.
3. Data Traffic On.
4. Roaming  
 R: Data roaming turned on.
5. New messages.
6. Wi-Fi:  
 Wi-Fi turned on.  
 Wi-Fi Type.  
 Number of connected Wi-Fi devices.
7. Battery.
8. Carrier Name  
 Display Registered Carrier Name
9. Total flow having generated.




Method 2: Charge the device through a computer connection Use the data cable provided with your device to connect the Mobile WiFi to the computer.



## SSID and Wireless Network Encryption Key

When a Wi-Fi device establishes a connection to the Mobile WiFi for the first time, you may need to enter the default Service Set Identifier (SSID) and wireless network encryption key.

The default SSID and encryption key are printed on the Mobile WiFi label. It is recommended that you log in to the web management page and change your SSID and network encryption key.



## Turning on the Mobile WiFi


Press and hold the  button until the screen lights up, indicating that the Mobile WiFi is turned on.

### Note:

Press and hold the  button to turn off the Mobile WiFi.

### Verifying the PIN

If the Mobile WiFi network parameters have been correctly configured but you cannot access the Internet after powering it on, PIN verification may be enabled. Log in to the web management page and enter the PIN when prompted. To avoid entering the PIN every time you power on the Mobile WiFi, disable PIN verification from the web management page. The PIN/PUK is delivered with your SIM card. For more details, contact your service provider.



## Connecting to the Internet

### Using an LTE, 3G, or 2G Network

By default, the Mobile WiFi management parameters have been preset according to your operator's requirements. The Mobile WiFi will be connected to the Internet after its startup. If data is transmitted, the Mobile WiFi will automatically connect to the Internet. If data is not transmitted for a period of time, the Mobile WiFi will automatically disconnect from the network connection.

### Note:

You can use the menu screen or log in to the web management page to enable or disable the automatic dialing while roaming function. If this function is turned off, when the Mobile WiFi enters a roaming network, it will automatically disconnect from the Internet connection that has already been established. You will need to manually establish this network connection again.

## Example 1: Connecting to a Computer (for example, running the Windows 7 operating system) through Wi-Fi

1. **Ensure that Mobile Wi-Fi function is on.**
2. Select Start > Control Panel > Network and Internet > Network and Sharing Center > Connect to a network.

### Note:

Before establishing a Wi-Fi connection, ensure that the computer is equipped with a wireless network adapter. If the computer indicates a wireless network connection, the wireless network adapter can be used. Otherwise, verify that your wireless network adapter is working properly.

3. Select the wireless network connection with the Mobile WiFi SSID and click Connect.

### Note:

If the wireless network connection is encrypted, enter the correct wireless network encryption key. To view the current SSID and wireless network encryption key, see the operations in the "SSID and Wireless Network Encryption Key" section.

4. Wait a moment for the wireless network connection icon to appear in the system tray in the lower right corner of the computer screen. The wireless network connection is then established.

## Logging In to the Web Management Page

Make sure the connection between the Mobile WiFi and the Wi-Fi device or computer is working normally.

2. Open the browser, and enter <http://192.168.225.1> in the address box.

### Note:

If the IP address conflicts with other IP addresses on the network, the IP address of the Mobile WiFi automatically changes. Check the current IP address on the Mobile WiFi screen.


3. Enter the user name and password to log in to the web management page.

### Note:



The default user name is admin.  
The default password is admin.

## Example 2: Connecting to a Game Console (for example, PSP) through Wi-Fi

1. On the PSP, turn on the WLAN.
2. Choose Settings > Network Settings.
3. Select Infrastructure Mode.
4. Select New Connection, and enter the connection name.
5. Select Scan to search for wireless networks. A list of access points will be displayed on the screen.
6. Select the access point with the Mobile WiFi SSID, and press the  button on the PSP. Confirm the SSID, and enter the correct wireless network encryption key.



7. Press the  button to proceed to the next step, and then press the X button to save settings.
8. Select Test Connection to test whether the network connection is successful.
9. You can now open the browser and access the network.



## Battery Saving Mode

If the Mobile WiFi has been inactive for some time, the Mobile WiFi enters the standby mode, in which the display screen turns off. Pressing any button causes the display screen to light up.

When the Mobile WiFi is being powered only by the battery, you can choose to enable or disable the automatic Wi-Fi off function. **If this function is enabled and no Wi-Fi devices access the Mobile WiFi for a period of time, the Wi-Fi turns off automatically.** You can press any button to turn the Wi-Fi on again.

## Establishing a WPS Connection

If the Wi-Fi device to be connected to the Mobile WiFi supports WPS, the wireless network encryption key is generated automatically and there is no need to enter it manually.

The steps for WPS connection are as follows:

1. Turn on the Mobile WiFi.
2. Turn on the Wi-Fi device to be connected to the Mobile WiFi.
3. Long press the WPS button to activate Mobile WiFi WPS.

### Note:


For specific instructions for the Wi-Fi device, refer to the device's user manual.

## Example 3: Connecting to a Tablet Computer (for example, iPad) through Wi-Fi

1. Touch Settings > WLAN to turn on WLAN.
2. The tablet computer automatically searches for wireless connections and displays a list of access points.
3. Select the access point with the Mobile WiFi SSID.
4. If required, enter the correct wireless network encryption key, and tap Join. (The lock icon indicates that the encryption key is required to connect to this wireless network.)


### Note:

Wi-Fi devices, such as an iPhone, iPod touch, PS3 and NDSi, can all access the Internet through the Mobile WiFi. For specific operations, refer to the Wi-Fi device's user manual.



## Restoring to Factory Settings

If you forget the user name, password, or SSID you have set, you can restore the settings on the web management page to their factory values. To do so, simply press and hold the RESET button until the Mobile WiFi restarts.



## Tips

When the Mobile WiFi is in use for an extended period of time, it will become warm and may overheat. Should this happen, the Mobile WiFi will automatically close the network connection and turn off to protect itself from damage. If this occurs, place the Mobile WiFi in a well ventilated space to allow the heat to dissipate, then turn it on and continue to use it as normal.

If you are unable to use the Mobile WiFi as normal, try the following:

- Consult the online help on the web management page.
- Restart the Mobile WiFi.
- Restore the Mobile WiFi to the factory settings.
- Consult your operator.

## Compatible system:

- Windows 7/8/8.1/10;
- MacOS 10.7/10.8/10.9/10.10